



EV West - Dilithium BMS Power and Warning Light Loops

Revision 1.0



Note: Must send **enable** **loopoc** command to BMS for open collector outputs on LP1 and LP2.

