




EV West - Hyper 9 System Non-Iso System - 120V - MCU,MFD

Revision 1.4 - 5/26

Note: This schematic is **only** for the NON-ISO AC-X1 NetGain/SME Inverter.

Note: For correct operation you must configure the Dilithium BMS Mappable Outputs by sending the following commands through the serial interface (Putty):

```
SEND: mcu> set out1 fault
SEND: mcu> set out2 plugin
SEND: mcu> set out5 power
```



Battery Enclosure - Tesla Battery Module
3S, 4S, or 5S

For H9 HV Systems, Please See ISO Schematic.

To complete, please see separate
Battery Schematic.

